

Part C T800-22-0000

Base Station/Repeater Rack Frame

This part of the manual is divided into three sections, as listed below. There is a detailed table of contents at the start of each section.

Section	Title
1	General Information
2	Circuit Operation
3	T800-22-0000 PCB Information

