

# Part F Installation

This part of the manual is divided into the sections listed below. These sections give a brief description of the basic rack mounting and wiring procedures for the T835 receiver, T836 transmitter, T837 exciter and T838 power amplifier.

Section	Title	Page
<b>1</b>	<b>T835/836/837 Installation</b>	<b>1.1</b>
1.1	Rack Mounting	1.1
1.2	Rack Wiring	1.2
1.3	Power Supply	1.3
1.4	Reverse Polarity Protection	1.3
<b>2</b>	<b>T838 Installation</b>	<b>2.1</b>
2.1	Rack Mounting	2.1
2.2	Rack Wiring	2.2
2.3	Power Supply	2.3

Figure	Title	Page
1.1	T800 Series Guide	1.1
1.2	T835/836 Chassis Connectors	1.1
1.3	T837 Chassis Connectors	1.1
1.4	T835 D-Range Wiring - Rear View	1.2
1.5	T836/837 D-Range Wiring - Rear View	1.2
2.1	T838 Guide	2.1
2.2	T838 Chassis Connectors	2.1
2.3	T838 Latched Position	2.2
2.4	T838 D-Range Wiring - Rear View	2.2

