

Part A General Servicing Procedures

This part of the manual is divided into the sections listed below. These sections provide some general and advisory information on servicing procedures, a brief history of T800 programming software, and a list of Technical Instructions pertaining to T830 Series equipment.

Section	Title	Page
1	General	1.1
1.1	Caution: CMOS Devices	1.1
1.2	Caution: Beryllium Oxide & Power Transistors	1.2
2	Mechanical	2.1
2.1	Pozidriv Recess Head Screws	2.1
2.2	Disassembly/Reassembly	2.1
3	Component Replacement	3.1
3.1	Leaded Components	3.1
3.1.1	Desoldering Iron Method	3.1
3.1.2	Component Cutting Method	3.1
3.2	Surface Mount Devices	3.2
4	To Remove Cased Mica Capacitors	4.1
5	Software History	5.1
5.1	BASEPROG V1/PGM800 V2	5.1
5.2	PGM800 V2.01	5.1
5.3	PGM800 V2.21	5.2
5.4	PGM800Win V1.00	5.2
6	Technical Instructions	6.1

Figure	Title	Page
1.1	Typical Anti-static Bench Set-up	1.1

